






CE  
07  
EN 14428:2008+A1

## INSTALLATION INSTRUCTION

BATH WALL




### MAJA PLUS

It is necessary to make sure before installation that electricity or water fittings in the walls, floors or outdoors will not be damaged because you are responsible for their defect. It is necessary to clean the installation place and glasses before installation using a standard glass cleaner. Only the sanitary silicone may be used for installation. The glass products contained in the package have to be protected against direct contact with tiles or ceramics. When they are unpacked, they can be put on the carton or inserted into U-profiles held in the set. When the glass is erected, sudden or strong movements should be avoided. All the installation works have to be carried out consistently, following the instruction, so that the product would be qualitative in the end and so that the shower enclosure would be hermetic. All the dimensions are indicated in millimeters.



UAB BALTIJOS BRASTA  
Palemono g. 7B, LT-52158 Kaunas, Lietuva  
Tel. + 370 37 45 70 21 Faks. + 370 37 45 37 32  
El. p. [info@baltijosbrasta.lt](mailto:info@baltijosbrasta.lt)  
[www.baltijosbrasta.lt](http://www.baltijosbrasta.lt)

## BATH WALL



Sizes of standard shower enclosure:


1. A=695-704 mm
2. A=795-804 mm
3. A=895-904 mm
4. A=995-1004 mm
5. A=1095-1104 mm

Available sizes of non-standard shower enclosure:

1. A=600...1200mm



1

Bath wall is composed of two glass - A and B.




2

Put the lower gaskets under the wall profile and mark the fixing places for wall profiles.




3

Drill the holes in the marked places. The hole's diameter is 6mm.






4

Smear silicone on the "back" of the profile before fixing the wall profile to the wall.



5

Fix the wall profiles to the wall. The lower profile attaching double-sided adhesive tape.




6

Insert the door construction into the fixed profiles. Use the level and pads to make the enclosure's top even. The adjustment place is left in the enclosure. The enclosure may need adjustment because of uneven walls or floors. The limit of wall profile is 12mm.


Connect the wall profile and door construction by 3 screws. Make the holes by 3,5 mm drill. Make the holes from top to the bottom in ~ 50mm distance and one in the middle. Before screwing up the screw, put the ring to fasten the screw's cap. Screw the cap on.

Attach the upper cab bracket. First place holder on the part of the glass. Invoked holder tighten with the key. Wall bracket part drill a hole. The distance from the edge of the wall profile to drill holes in the center is 160-180mm. Attach the wall bracket of the screw.




7

The height of doors is adjusted with the help of hinges. (Release the hinges and change the glass' position until the tops of all the glasses are in the same line). When finished regulation of doors tighten the screws in the bottom of hinges with screwdriver.



8

Put the lower gasket of the doors as indicated.



9

Seal collected bath wall with silicone from the inside. Do not use the door 24 hours until firm silicone.

